

Tech Note UV100-102

UV-100 Hush Kit Installation Procedure

1. Remove UV-100 back panel.
2. Carefully pull out UV-100 pump board to expose pump.
3. Clip cable tie holding micro pump to UV-100 pump board. Note the hose and electrical connections to the pump in case any connections are broken in installation.
4. Slip micro pump into slot in the hush kit, Making sure connections are not broken.
5. Place hush kit body along side the pump board and compress it slightly to fit. Slide the kit and the board into the enclosure at the same time. The hush kit should fit flush with the board.
6. Reinstall the UV-100 back panel.
7. Test unit for proper reading.

